

CHAPTER 1.1.4.

METHODS FOR DISINFECTION OF AQUACULTURE ESTABLISHMENTS

1. General principles

Disinfection is employed as a common disease management tool in aquaculture establishments. It may be used as a routine practice in biosecurity programmes designed to exclude specific diseases, as well as a routine sanitary measure employed to reduce disease incidence within farms, or it may be used in disease eradication (stamping out) efforts. The specific reason for disinfection, will determine the disinfection strategy used and how it is applied.

The general principles pertaining to disinfection of aquaculture establishments involve the application of chemical treatments in sufficient concentrations, and for sufficient periods, to kill all pathogenic organisms that would otherwise gain access to surrounding water systems. As the inherent toxicity of disinfectants prohibits safe use in open water, or open water systems, disinfection can only reasonably be applied to hatcheries and tank holding facilities. In addition, as some aquaculture establishments are generally seawater based, compounds produced during seawater disinfection (residual oxidants) must also be disposed of carefully.

The choice of disinfection procedures depends on the size, type and nature of the materials and facilities to be disinfected. Surfaces to be disinfected may include fabric or woven material (clothes, nets), hard surfaces (plastic, concrete) or permeable materials (earth, gravel). Disinfection is more difficult on permeable surfaces and requires more time.

As the presence of organic matter will reduce the disinfection capacity of most disinfectants, filtering influent water is recommended. In addition, all surfaces must be thoroughly cleaned prior to disinfection. The detergent used must be compatible with the disinfectant and both must be compatible with the surface being treated (e.g. iodophor solutions are generally acidic so cannot be used on concrete, which is alkaline). Ensure that the waste produced from washing is disinfected before disposal. Complete coverage of the surfaces is required, e.g. using a high pressure spray or soak.

Disinfection procedures must be established and used according to the objectives of disinfection and identified risks. Diseased aquatic animals, animal fluids and tissues (e.g. viscera, blood, mucus, faeces), and their contact with equipment and workers present a risk of transmission of pathogens that could eventually infect healthy aquatic animal populations.

Basic disinfection protocols include the removal of all aquatic animals, dead and alive from the facility, a cleaning programme that is designed to eliminate all the remaining organic matter adhering to the surfaces, the use of disinfectants on equipment and installations and a final neutralisation step using chemical products.

When removing aquatic animals from the facilities prior to disinfection, the direct disposal of diseased populations of aquatic animals of any life stage or age into receiving waters is a hazardous practice that facilitates the spread of disease from farmed to wild populations or to neighbouring farms using the same water supply. Such disposal should not be permitted. When the decision is made to discard a population due to the presence of disease, the stock should be harvested or humanely killed. In the case of land-based aquaculture establishments, the tank, raceway, or pond, etc., should be disinfected prior to discharge and again prior to restocking.

The washing and disinfection procedures should include at least the following stages:

- a) Removal of solid waste, etc., followed by prewashing,
- b) Deep cleaning and washing,
- c) Disinfection,
- d) Rinsing.

The process should be monitored throughout by a technically competent person and records kept.

It is essential to provide protection from contact with hazardous substances by wearing protective clothing, face masks, eye protection, etc., as appropriate.

The disinfectants must be stored in a way that presents no direct or indirect danger to animal or human health and the environment.

2. Occurrence of listed diseases

43 When an OIE listed disease, or an important but unlisted emerging disease occurs for the first time at a particular farm, at a particular site (i.e. at
44 a quarantine facility), or within a region or country previously believed to be free of that disease, it may be advisable, if not required, to eradicate
45 the disease by depopulating the facility and performing a thorough disinfection of all or part of the facility. Following of the affected facility for a
46 defined period of time may be warranted in some situations (see Chapter 1.7.1, Guidelines for following in aquaculture in the *Aquatic Code*).

47 **3. Prevention of disease spread to wild populations**

48 The direct disposal of diseased populations of an aquatic animal (any life stage; i.e. fertilised or unfertilised eggs, larvae, postlarvae, juveniles, or
49 adults) or waste products derived from them (i.e. processing plant wastes such as blood, viscera, shells, broken shrimp pieces, etc.) into receiving
50 waters (i.e. creeks, rivers, estuaries, bays, littoral areas) is a dangerous practice that facilitates the spread of disease from farmed populations to
51 wild aquatic animal stocks or to neighbouring farms that use the same water supply, and it should not be permitted to occur. With cultured stocks,
52 when the decision is made to discard a population (i.e. that is being cultivated in a hatchery tank or growout pond) due to the presence of disease
53 (or poor culture performance which may be due to an undiagnosed disease), the stock in the tank or pond should be harvested and/or humanely
54 killed in the tank or pond. The water in the tank or pond should be disinfected prior to discharge. The emptied tank or pond should be disinfected
55 prior to restocking.

56 **4. Routine sanitation and biosecurity**

57 Many aquaculture establishments, especially those cultivating early stages of aquatic animals, employ measures that use a number of disinfection
58 methods for disease prevention and control. These measures may be part of a farm's routine biosecurity programme that may be designed for
59 exclusion of specific diseases as well as serving as general pest and disease exclusion measures.

60 **4.1. Disinfection of eggs and larvae**

61 **4.1.1. Guidelines for disinfection of fish eggs**

62 Disinfection of eggs with iodine can be carried out for the various fish species, but it is most commonly used for eggs of fish of the
63 Salmonidae family (salmon, trout and char). Although generally effective for decontamination of surfaces of eyed and newly fertilised
64 eggs, the use of disinfectants, such as iodophors, may not always prevent vertical transmission of some bacterial pathogens (e.g.
65 *Renibacterium salmoninarum*) and viral pathogens (e.g. infectious pancreatic necrosis virus) that may be present within the eyed and
66 newly fertilised egg.

67 **4.1.2. Eyed eggs of salmonid fish**

68 There are a number of protocols regularly used to disinfect eyed eggs. In general, the pH of the solutions of the iodophor product
69 must be between 6 and 8. At a pH of 6 or less, the toxicity for eyed and newly fertilised eggs increases, and at 8 or more, the
70 disinfection efficacy decreases. It is therefore essential to control the pH, and 100mg/litre of NaHCO₃ must be added to water with a
71 low alkalinity value. It is recommended that the eggs be rinsed in clean fresh water, or 0.9% saline, before and after disinfection and
72 that an iodophor solution giving 100ppm free iodine in 0.9% saline free of organic matter be used as the disinfectant solution. The
73 contact time at the concentration of 1 litre of 100ppm of iodophor solution should not be less than 10 minutes and the solution should
74 be used only once.

75 **4.1.3. Newly fertilised salmonid eggs via a water-hardening process**

76 For disinfecting newly fertilised salmonid eggs via a water-hardening process with iodophors, the active iodine concentration should
77 100ppm. One such procedure is as follows:

- 78 • Eggs should be stripped and separated from ovarian fluid, rinsed in 0.9% saline (30–60seconds), sperm added and
79 fertilisation allowed to proceed for 5–15 minutes.
- 80 • The eggs should then be rinsed in 0.9% saline (30–60 seconds) to remove excess sperm and other organic materials.
- 81 • The eggs should then be rinsed in a 100ppm iodophor solution for 1 minute, that solution discarded and replaced with a fresh
82 100ppm solution and the eggs disinfected for a further 30minutes, and this solution, and the rinsing solutions, should be used
83 only once. The ratio of eggs to iodophor solution should be a minimum of 1:4.
- 84 • The eggs should be rinsed again in fresh or sterile hatchery water for 30–60 seconds.
- 85 • Water-hardening should be finished using clean-water.

86 It is important that eggs must not be fertilised in the presence of the iodophor solution as this will kill sperm cells

87 4.1.4. Eggs of other fish species

88 For other species, preliminary tests should be conducted to determine at what egg stage and iodophor concentration, disinfection can
89 be carried out safely. Disinfection of eggs of marine species, such as plaice, cod and Atlantic halibut, for which some adverse effects
90 of iodophors have been documented, may be achieved with 400–600 mg/litre glutaraldehyde with a contact time of 5–10 minutes.
91 However, this is not effective against nodaviruses for which the use of ozone at 1 mg O₃/litre for 30 seconds is recommended. A
92 concentration of ozone of 0.1–0.2 mg O₃/litre for 3 minutes inactivates most pathogenic fish bacteria as well.

93 4.1.5. Efficacy limits

94 Disinfection of eggs with iodophor may not always be effective in preventing vertical transmission of infectious pancreatic necrosis
95 virus, *Renibacterium salmoninarum* and infectious haematopoietic necrosis virus, for which this method was developed initially. The
96 ineffectiveness of iodophor disinfection in some instances has been proven by epidemiological studies and laboratory tests.

97 4.1.6. Mollusc eggs and larvae

98 Disinfection of eggs and larval stages is not considered practical for most molluscan systems. In addition, there is little information
99 on specific disinfection procedures for pathogens of molluscs (i.e. *Marteilia* spp., *Haplosporidium* spp., *Bonamia* spp., *Perkinsus* spp.,
100 iridovirus and pathogenic levels of marine microbes) or seawater. Therefore, disinfectants and concentrations are based on related
101 pathogens or seawater sterilisation. Three stages of disinfection can be applied to hatcheries:

- 102 a) pretreatment of influent water, e.g. filters (1.0 and 0.22 µm) or chemical disinfection protection of stocks of molluscs;
103 b) treatment within the facilities (especially recycling systems) = protection of stocks of molluscs;
104 c) treatment of effluent water = protection of the environment.

105 **4.1.7. Disinfection of eggs and larvae in penaeid shrimp hatcheries**

106 Certain penaeid shrimp viral diseases (i.e. Spherical baculovirus, Tetrahedral baculovirus, Hepatopancreatic parvovirus infections)
 107 are transmitted by faecal contamination of spawned eggs. These diseases, as well as infections due to certain other shrimp viruses
 108 such as White spot disease virus, and certain bacterial and fungal disease agents, can be eliminated or have their incidence reduced
 109 through the routine use of disinfection protocols when used to surface disinfect eggs and/or recently hatched nauplii. A widely used
 110 method is given below:

111 For fertilised eggs¹

112 Collect fertilised eggs. Rinse with running seawater for 1–2 minutes. Fully immerse eggs in 100 ppm (parts per million) formalin for
 113 1 minute. Fully immerse eggs in iodophor (0.1 ppm iodine) for 1 minute. Rinse in running seawater 3–5 minutes. Transfer to disinfected
 114 larval rearing tanks.

115 For nauplii²

116 Using phototactic response to light, collect nauplii with netting or screen. Rinse with running seawater for 1–2 minutes. Fully immerse
 117 nauplii in 400 ppm formalin for 30–60 seconds. Fully immerse nauplii in iodophor (0.1 ppm iodine) for 1 minute. Rinse in running
 118 seawater 3–5 minutes. Transfer to disinfected larval rearing tanks.

119 **4.1.8. Precautions**

120 Certain precautions must be taken prior to the use of iodophors as products on the market contain a variable quantity of detergents
 121 that can give rise to toxic effects. It is therefore recommended that preliminary tests be carried out among the products on the
 122 market. It is advisable to build up stocks of the most satisfactory product. However, expiry dates must be observed. It is also
 123 important that any chemicals used for disinfection of eggs are used in compliance with the relevant health and safety and
 124 environmental protection regulations of the country that they are used in. Finally, in the case of eggs that have been transported, the
 125 packaging should also be disinfected or, better still, destroyed in a manner that will not pose a risk of contamination of water and/or
 126 a health risk to other fish at the end destination.

127 **4.2. Materials and equipment**

128 All the equipment used for feeding, cleaning, and for removal of dead aquatic animals should be unique to each culture unit.

129 The food management containers in the different units should be different from the ones used for mortality and should be carefully washed
 130 and disinfected, following the established systems, at least three times a week with the products authorised.

131 The machinery used in an aquaculture establishment should never be transported to another aquaculture establishment, unless the latter
 132 does not contain aquatic animals. Only in exceptional cases is machinery allowed to be transported after it has been washed and disinfected
 133 with products authorised.

134 The remaining machinery used should be washed and disinfected with products authorised before entrance to and departure from the farm.

135 In the case of aquaculture establishments in the sea, nets should never be changed from one aquaculture establishment to another, even if
 136 they have been washed and disinfected.

137 In the case of modules, floating store rooms, and automatic feeding systems, all should be washed and disinfected before changing the
 138 location of the units. In freshwater, these never have to be changed among the aquaculture establishments.

139 **4.3. Nets**

140 All nets shall be washed after being taken out of the water. Nets that have not been washed after being submerged in a body of water shall
 141 not be reincorporated into another body of water. Once the net has been removed from the water, it shall be transferred as soon as
 142 possible to the net washing site, thus avoiding these nets contaminating other nets, equipment and working areas. The transfer of nets from
 143 and towards the wash shops shall be carried out using the appropriate watertight compartments or packaging, thus preventing any cross-
 144 contamination.

1 Fertilised eggs are more sensitive than nauplii to formalin.

2 Nauplii are much easier to collect than are fertilised eggs in hatcheries.

145 Farms requiring washing services and eventual impregnation of the nets with anti-scaling products shall carry out this operation in
146 authorised net shops.

147 The washing process must guarantee the elimination of all the elements adhered to the nets, such as eggs and/or larvae of parasites,
148 molluscs, equinoderms, algae, organic matter, etc.

149 **4.4. Vehicles**

150 Regarding vehicles, the aquaculture establishment's manager (or whomever he or she designates) should ensure that the following
151 requirements are met:

152 • only vehicles that serve the aquaculture establishment should be given access to the production areas or transit zones, and can
153 enter these areas for a determined purpose only; temporary service vehicles, visiting vehicles or workers' vehicles should not have
154 access to these areas.

155 • all vehicles that enter the production areas or transit zones, with no exception, must be disinfected when entering and leaving the
156 aquaculture establishment, using products authorised for that purpose.

157 • the manager of the aquaculture establishment (or whomever he or she designates) should demand a "disinfection certificate" or
158 similar, before a transport vehicle is given access to the production units. The certificate should confirm that the vehicle's tanks into
159 which the aquatic animals will be loaded have been disinfected.

160 • all people entering with a vehicle must follow the disinfection protocols established for the aquaculture establishment.

161 • vehicles and containers that serve more than one centre must be disinfected daily, and the "disinfection certificate" or similar that
162 accredits the procedure should be demanded periodically.

163 • a register of all the vehicles that enter the dependences or transit zones must be kept. The register must contain at least: the date,
164 hour, company, reason for the visit, name of the driver and last visited centre.

165 • vehicles for different services should not enter the dependences of the farm at the same time, particularly vehicles used for the
166 collection of dead aquatic animals ("mortality trucks").

167 The following should be considered when selecting products and procedures to be followed:

168 • the effectiveness of detergents and disinfectants in dealing with the different type of materials and surfaces,

169 • the location inside the farm of the areas or items to be disinfected,

170 • the manufacturer's recommendation regarding the detergent and/or disinfectant, and other variables that may be relevant to the
171 type and level of contamination that the surfaces may have.

172 **4.5. Staff**

173 Before entering a production area, all staff should put on their protective clothing (overall, coat, gloves, boots, chest-protector); then both
174 boots and hands should be disinfected. It should be strictly forbidden to enter the area without the authorised protective clothing.

175 No person should exit the facility wearing a working outfit, even if they have transited through the sanitary barrier and disinfected their
176 shoes and hands.

177 **4.6. Pipelines and tanks**

178 Routine disinfection of pipelines and tanks is highly recommended; the frequency of disinfection will vary according to the turnover of the
179 aquatic animals stocks. High concentrations of aquatic animals should be rotated between disinfected tanks as often as practical and/or
180 kept in seawater that has been disinfected with ozone or chlorine and subsequently neutralised. Each new batch of aquatic animals
181 introduced into a facility should be placed in pre-disinfected tanks.

182 Regular air- or heat-drying of pipelines (daily), tanks and other equipment (e.g. algal culture carboys), in addition to disinfection of their
183 surfaces, is also recommended (especially for disease outbreaks of unidentified aetiology).

184 a) Chlorine is usually applied as sodium hypochlorite (Chlorox®, household bleach, etc.). Fill all pipelines with 50mg chlorine/litre (=
185 50parts per million [ppm]). Allow an exposure time of at least 30 minutes before flushing with clean water. This solution is effective
186 against most microbial agents. Chlorinated water must be neutralised prior to release from the holding facility. Optimal neutralisation
187 is achieved by passage through activated charcoal (removes excess chlorine and chloramines). Reducing agents such as sodium
188 thiosulfate or aeration (which do not remove toxic chloramines) may also be used.

189 b) Iodophors are generally applied as alkaline solutions (Wescodyne®, Betadine®) at 200–250mg iodine/litre (ppm) with a contact time
190 of at least 10minutes.

191 NOTE: Iodophors are not effective against certain protozoans in suspension, e.g. over 1000mg iodine/litre is tolerated by
192 *Labyrinthuloides haliotidis* of abalone. Iodophors may be effective against protozoan parasites following air or heat drying of tank
193 surfaces and pipelines.

194 4.7. Disinfection of source water

195 Because several of the listed diseases of aquatic animals listed in the *Aquatic Code*, as well as a number of other important diseases, can
196 be introduced into farms with source water when it contains vectors or carriers (i.e. wild infected crab or shrimp larvae, wild fish, etc.),
197 some farms operate biosecurity plans that include provisions for the disinfection of source water. This may be accomplished by a variety of
198 means that may include one or some combination of the following procedures:

199 a) For filtration of source water – source water is pumped into a supply/settling canal where it first passes through coarse bar
200 screens to remove large aquatic animals and debris. Then the water is passed through a series of progressively finer screens, and
201 final filtration is accomplished by passing source water through a fine mesh (150–250µm mesh size) bag screen before being
202 introduced into a culture pond or storage reservoir.

203 b) Instead of using mesh nets, some farms place filtration structures in the supply channel. A series of compartments within these
204 structures are filled with filter matrixes, beginning with coarse gravel for initial removal of large aquatic animals and debris, an
205 intermediate section which contains a finer matrix of sand and gravel, and the end section which contains fine sand.

206 c) For chlorination and de-chlorination, source water is pumped to a supply channel or directly into culture ponds or reservoirs (with or
207 without filtration) and treated with sufficient chlorine to kill any potential vectors or carriers in the source water.

208 d) 'Zero' or reduced water exchange: Some farms use supplemental aeration and re-circulation of water in culture ponds and within the
209 supply and discharge systems of the shrimp farm to reduce source water requirements. This reduces the volume of source water
210 that must be disinfected before use, as well as reducing nutrient loss from farms with effluent.

211 4.8. Disinfection of effluent water

212 a) Ozone has been used successfully in controlling the microbial content of effluent water from quarantine facilities. Residual
213 compounds, formed as a result of the interaction of ozone with seawater (residual oxidants), at levels of 0.08–1.0mg/litre are
214 considered sufficient to significantly reduce live microbes (principally bacteria).

215 NOTE: The measurement of residual ozone in seawater is problematic due to the rapid and continuous formation of oxidant products
216 in seawater. Residuals formed between ozone and seawater (hypobromite, bromine or hypobromous acid) are toxic to early stage of
217 aquatic animals) and should be removed using a charcoal filter before passing through/out of the mollusc facility. UV treatment of
218 seawater post-ozonation may be required for complete sterilisation, e.g. for quarantine.

219 b) Chlorine administered as sodium hypochlorite at a concentration of 25mg chlorine/litre is effective against certain protozoans (*L.*
220 *haliotidis*); however, 50mg chlorine/litre is recommended for complete microbial sterilisation. Higher concentrations may be used
221 under certain conditions (e.g. quarantine); however, these require proportionately greater neutralisation treatments and exhaust
222 systems to deal with the toxic fumes produced.

223 c) Iodophors are not as effective as the above two treatments for killing protozoans.

224 4.9. Buildings

- 225 The disinfection regime used should be building-specific and dependent upon the use-pattern of that particular building.
- 226 i) Office buildings: these buildings would most often be subject only to foot traffic from people who have been in contaminated buildings
 227 or culture areas. Because of this, the greatest focus of attention should be the floors and cold storage units in the building. Floors
 228 should be thoroughly cleaned (if they are non-porous) with standard detergents and cleaning solutions, followed by a thorough drying.
 229 If the floors are carpeted, they should be vacuumed and cleaned with a detergent appropriate for carpets, or 'steam' cleaned. All
 230 other areas within these buildings, such as walls, bathrooms, desks, refrigerators, freezers, etc. should be examined for possibly
 231 contaminated materials (i.e. frozen shrimp in freezers) and any such item found and its container should be cleaned and disinfected
 232 or disposed of in a sanitary manner.
- 233 ii) Culture buildings: it must be assumed that these buildings have had direct contact with the disease agents and will therefore be
 234 handled in a different manner from that of the office buildings. The disinfection regime for these buildings will consist of two steps.
 235 First, the building should be thoroughly swept and/or vacuumed (where appropriate) to remove as much large-sized organic and
 236 inorganic debris as possible. This should be followed with the second step, treatment with chlorine. Chlorine solution (~1600ppm)
 237 should be applied (by spraying) to all surfaces which are not prone to the corrosive actions of chlorine. Those surfaces which should
 238 not be chlorinated, can first be sponged with a iodophor solution minimally providing 200ppm of free iodine. These can then be
 239 covered with plastic or any other protective material. Floor surfaces can be soak-chlorinated to a depth of 5cm with a 200ppm
 240 chlorine solution. This should be allowed to set for a minimum of 48 hours. If many of the sprayed surfaces are somewhat susceptible
 241 to corrosion by chlorine, those surfaces can be freshwater-rinsed after the 48-hour treatment.
- 242 In buildings where disinfection with chlorine is not practical, fumigation with formaldehyde gas should be considered. After a general
 243 cleaning, fumigation of a sealable building can be initiated. The entire process, from the time the building is first gassed until it can be
 244 occupied again, should take a minimum of 36–60 hours. The entire building must be totally sealed off during the actual fumigation;
 245 there should be no means by which the gas can escape once it is placed in the building. If possible, the electrical service for the
 246 building should be turned off. The required environment for formaldehyde gas disinfection is a minimum temperature of 18°C with a
 247 high relative humidity (at saturation is best, i.e. floors should be wet, etc.). Generation of formaldehyde gas is accomplished by the
 248 addition of 17.5g potassium permanganate to each 35 ml of 100% formalin (a 37–39% aqueous solution of formaldehyde gas) for
 249 each 2.83 m³ (100 ft³) of space. Ideally, each room in the structure should have its own source of formaldehyde gas to assure that all
 250 areas of the building are uniformly treated. The correct amount of each compound (potassium permanganate and formalin) should be
 251 weighed out into separate containers, the formalin should be placed in a non-plastic container that is at least 10 times the combined
 252 volume of both the formalin and the potassium permanganate. (The person applying a formaldehyde gas fumigation should wear
 253 waterproof outer ware to protect their skin, an approved formaldehyde gas mask, and goggles or a face shield for eye protection.)
 254 The containers with the proper amounts of the two reagents should then be placed on the floor in the centre of the room, on a large
 255 disposable protective (plastic) mat. The formalin and potassium permanganate should not be mixed at this time. Once all rooms have
 256 the correct amounts of the two compounds, the building has been completely sealed and the environment modified as necessary, the
 257 actual fumigation can begin. The mixing of the two compounds must be done very rapidly and carefully as the reaction is immediate
 258 and somewhat violent as formaldehyde gas is emitted. Starting with the room farthest from the exterior door, add the permanganate
 259 to the formalin and proceed to the next room. After all rooms have been completed, lock the exterior door and seal it from the outside
 260 with tape. The building should be allowed to set for a minimum of 12 hours. After this disinfection period the building should be flushed
 261 with clean air for 24–48 hours. There should be no detectable odour of formaldehyde when people are allowed to reoccupy the
 262 building.
- 263 An alternate method for the generation of formaldehyde gas is the sublimation of powdered paraformaldehyde. For each 2.83 m³
 264 (100 ft³) of space, approximately 28g paraformaldehyde should be used. It can be sublimated by being placed in an electric fry pan,
 265 which has been set on high. This procedure is somewhat more dangerous, because formaldehyde is flammable and a spark from such
 266 a heating device could theoretically ignite the gas. The same procedures noted above for the formalin/permanganate mixture in
 267 regards to venting, etc. should also be followed for the use of paraformaldehyde.
- 268 iii) Processing buildings: these buildings are typically constructed to permit routine disinfection. For the most part, the procedures
 269 followed in the routine operation of such buildings are appropriate for a TCU, provided that the building, its cold rooms, and its
 270 freezers are also disinfected and thoroughly dried. If considered necessary, fumigation with formaldehyde gas may be done to insure
 271 destruction of the disease agent(s) of concern.
- 272 iv) Other buildings: buildings (feed storage, maintenance, tool rooms, etc.) should be treated somewhat like the office building. Care
 273 should be taken to remove all the large-sized debris, which would normally be found in relative abundance within these types of
 274 buildings. Potentially contaminated surfaces within such buildings should next be spray-chlorinated and allowed to set for 24–
 275 48 hours. This should be followed by a freshwater rinse. All equipment, which should not be exposed to the corrosive action of
 276 chlorine, should be removed before the spraying, and they should be disinfected by surface disinfection with 200ppm of iodophor.

277
278

Once the equipment has been disinfected, it can be brought back into the building. Fumigation with formaldehyde gas is another option for this type of building.

279 4.10. Clothing and equipment

280 Clean surfaces with detergent and disinfectants prior to proper disinfection.

- 281 a) Iodophors (e.g. Wescodyne®, Betadine®) at 200–250 mg iodine/litre can be used as a footbath. NOTE: Iodophors will stain clothing.
- 282 b) Chlorine (household bleach solution at 50 mg chlorine/litre) is also an effective footbath or equipment wash.
- 283 c) Sodium hydroxide (1% NaOH + 0.1% Teepol® or other detergent) makes an effective footbath for rubber boots. NOTE: Do NOT use for
284 dress shoes/boots.

285 5. Crustacean hatcheries and broodstock rearing/holding facilities

286 Virtually all penaeid shrimp hatcheries and broodstock holding/rearing facilities use seawater that has been disinfected to remove potential
287 pathogens, pests, and disease-carrying agents via mechanical filtration, UV irradiation, and/or chemical disinfection. This may be by passive
288 source water filtration (i.e. by the use of seawater wells or well points) or by mechanical filtration using high pressure pumps and a variety of
289 water filtration devices and pore sizes. Some facilities use filtration coupled with UV light disinfection of source water, while others use chemical
290 disinfection methods, using either chlorination and de-chlorination or high doses of ozone and subsequent removal of residual oxidants. Chemical
291 disinfection of source water typically requires the use of one or more water storage reservoirs in which the water is treated and detoxified before
292 use in the shrimp hatchery or broodstock facility. Numerous manuals are available that provide specifics on hatchery and broodstock facility
293 design and operation for shrimp culture, and in which details on source water disinfection are provided.

294 5.1. Disinfection of tanks, equipment, pipes, air stones, etc.

295 For routine sanitation, hatchery and broodstock tanks (i.e. tanks for broodstock maturation, matting, spawning, larval rearing and indoor
296 nursery) should be cleaned, disinfected and dried between use. Tanks used for the above-named purposes in crustacean (especially shrimp)
297 hatcheries are typically precast fiberglass tanks or they are constructed of concrete or wood and either coated or painted with resin-based
298 coatings (e.g. epoxy or fiberglass resin) or lined with plastic liners manufactured for that purpose. After harvest of the stock from the tank,
299 all loose objects and large-sized organic debris such as algae, faeces and left-over feed should be removed. With relatively small tanks, it is
300 advisable after harvest of the stock to fill the tank to capacity, immerse all nonporous corrosion resistant equipment (i.e. airlines, air stones,
301 stand pipes, screens, sampling containers, etc.) in the tank, and then add calcium hypochlorite to provide a minimum of 200 ppm of free
302 chlorine. This should be allowed to set overnight. After the proper chlorinated soak-time, the tank can be drained and freshwater rinsed.
303 Before draining the system, the treated water should be dechlorinated (see specific subsections on chlorination described in this Section),
304 unless appropriate effluent collection and treatment systems are in place. After the tank has been rinsed it should be allowed to completely
305 dry. In the case of large tanks, an initial cleaning to remove loose debris should be followed by disinfection with a concentrated (~1600 ppm
306 as chlorine) solution of calcium hypochlorite. All inside and outside surfaces should then be sprayed with this chlorine solution. The tank
307 should then be allowed to set for several hours and then rinsed, filled and flushed. Surfaces should then be scrubbed free of all remaining
308 material. After disinfection with chlorine, small or large tanks should be rinsed with clean water, then filled and flushed to ensure that no
309 chlorine residues remain before the tank is restocked for another crop.

310 5.2. Disinfection of growout ponds

311 Following the routine harvest of a crop from a growout pond (or from a large tank or raceway used for growout of a crop), the pond (tank)
312 bottom should be inspected. Large deposits of organic debris should be treated or removed. This is easily accomplished in lined tanks,
313 raceways, or ponds (i.e. by flushing with a high pressure hose), but poses more of a challenge in large earth bottom ponds. Many methods of
314 pond bottom disinfection and treatment between crops are practiced. These methods are given in detail in a number of shrimp farming
315 manuals, and some will be listed here only with minimal details:

316 5.2.1. Chlorination

317 This disinfectant may be used for routine treatment of ponds between crops or when disease eradication is the goal. After draining
318 the pond, remove (and dispose of [see section on carcass disposal in Section C.6]) as many animals from the system as is possible
319 (this may be difficult in pond systems where the removal of large numbers of dead shrimp would not be practical). Partially refill the
320 pond (or fill to capacity if required), discontinue the addition of new water, stop the discharge of effluent water, and remove any
321 internal or external sources of aeration or aeration devices, which might be subject to corrosion. Then evenly distribute sufficient
322 granulated calcium hypochlorite (such as Olin HTH™) to provide a minimum residual free chlorine concentration of 10 ppm within the
323 entire system's water. (NB: The person(s) applying the chlorine should wear waterproof outer ware to protect their skin, an approved
324 chlorine mask, and goggles or a face shield for eye protection.) Redistribute additional calcium hypochlorite as often as required to
325 maintain the residual concentration at near or 10 ppm. Allow the system to set for a minimum of 24–48 hours (especially if applied to

326 large systems) at this minimal chlorine concentration. The chlorine will kill all shrimp and most, if not all, of the other organisms
 327 occupying the water column or resident in the pond. After the pond has been treated with chlorine for the required minimum time and
 328 before any water is discharged, neutralise the chlorine either passively by exposure to sunlight and air for approximately an
 329 additional 48 hours (without the addition of new chlorine) or by the addition of sodium thiosulphate at a rate of five (5) molecules of
 330 sodium thiosulphate for each four (4) molecules of chlorine (or the weight of sodium thiosulphate being 2.85 times the weight of
 331 chlorine in the water, see example table below).

Pond size	Average depth	Volume	Chlorine dose	Chlorine required	HTH (65% active Cl)	Thiosulphate required
1 hectare	1 m	10,000 m ³	10 ppm	100 kg	154 kg	285 kg

332 **Periodic testing should be done for residual chlorine; water should not be discharged until it has reached 0 ppm.** Once the chlorine
 333 levels have been ascertained to be at 0 ppm, the system water can be safely dumped into the farm's effluent system. In some culture
 334 systems, in particular raceways, tanks and small lined ponds (i.e. those systems in which the majority of the shrimp were not
 335 removed prior to disinfection), the dead shrimp should be collected for proper disposal (see section on carcass disposal in Section
 336 C.6).

337 5.2.2. Liming

338 The lime, as calcium oxide or calcium hydroxide, should be applied to a very moist bottom at a rate of 5000 kg/ha or 1500 kg/ha,
 339 respectively. Great care should be taken to assure that the lime is spread evenly over the soil surface. The pond should then be
 340 allowed to set for at least a week, or at least until the soil has dried to the point of cracking to a depth of approximately 10–20 cm.
 341 Additional lime may be applied after ploughing (see below) at a rate of 50% of that normally prescribed. The pond should again be
 342 dried for at least a week, depending on the weather.

343 5.2.3. Drying and ploughing

344 Whether or not a pond is treated by chlorination or liming or left to dry untreated, ploughing is a commonly used method of treating a
 345 pond bottom to reduce its organic content, improve nutrient recycling, buffer pH, eliminate pests, and achieve disinfection through a
 346 combination of microbial degradation, exposure to sunlight, aeration, and desiccation. In some regions, drying and ploughing of dry
 347 pond bottoms may only be possible during the 'dry season'. When pond drying is an option, the pond bottom should be allowed to dry
 348 until the surface has cracked to a depth of approximately 10 cm. Once this level of drying has been reached, the soil should be broken
 349 up to a depth of approximately 20 cm with a plough, tiller, disk harrow, tine harrow or other similar farm implement. Ponds treated in
 350 this manner should be left for at least a week before being refilled and restocked.

351 5.3. Culture support equipment and systems

352 These are operational units of the shrimp culture facility which may be housed in a building.

- 353 i) *Artemia* systems: all *Artemia* decapsulation and cyst hatching units and tanks should be treated in the same manner as other
 354 tanks. They should be cleaned of all large debris, then filled to the top with clean water and calcium hypochlorite added to
 355 achieve a final concentration of 200 ppm (free Cl₂). Chlorination should be allowed to continue for 24–48 hours. The outside of
 356 such tanks may be spray-chlorinated (1600 ppm chlorine). Treated tanks can then be dechlorinated with sodium thiosulphate,
 357 drained, freshwater rinsed, and allowed to dry for a minimum of one week. Unopened containers of *Artemia* cysts at the
 358 facility can be retained. These should, however, be surface disinfected with chlorine (200 ppm) or iodophor (200 ppm).
- 359 ii) Algae systems: containers, tanks, incubators and rooms used to produce algae for feeding the larval stages of shrimp may be
 360 handled and disinfected in nearly the same way as other tanks systems. The only major difference being that special care must
 361 be taken to assure that all chlorine residues have been rinsed from the units before they are used again. In the case of the
 362 culture tubes, flasks, carboys, and flasks used to culture algae, a combination of acid (10% HCl) rinse or steam sterilisation
 363 can be used in lieu of disinfection with chlorine or iodophor.

364 Disinfection of stock cultures of living algae is not possible. The use of disinfection is clearly out of the question; any compound
 365 which would kill the disease agent would likewise kill the algae. Hence, there are two basic methods of minimising the chance of
 366 a disease agent being present in the stock cultures.

- 367 • Dilution: all stock cultures can be cloned from the existing stocks. Each culture should be diluted either by means of
 368 serial dilutions (for broth cultures) or streaked for single colonies (agar cultures). All dilutions must be performed
 369 using strict aseptic techniques with all media being properly autoclaved. Passages from the stock cultures should not

- 370 occur until the algae culture room has itself been disinfected as per the above building procedures. Once a culture has
 371 been diluted and cloned by either of these methods, to the point where there remains only one cell of the original culture,
 372 the risk is negligible that a (shrimp) disease agent may be present.
- 373 • New Stock Cultures: If existing stock culture are discarded in a TCU, new stocks should be purchased from algae supply
 374 laboratories, or obtained from other sources where contamination with (shrimp) disease agents is unlikely, such as
 375 isolating desired species from wild populations of algae. New stock cultures should not be obtained from any facility that
 376 also cultures shrimp and may be contaminated with (shrimp) disease agents of concern.
 - 377 iii) Farm equipment: nets, seines, porous air-line tubing, etc. which are relatively inexpensive and easily obtainable should be
 378 discarded and removed from the facility during a TCU rather than being disinfected as they are not readily disinfected and
 379 chlorine is likely to damage them and shorten their useful life.
- 380 Non-expendable equipment such as large size flexible plastic tubing, pumps and pipes, transfer tanks, cages, harvest cages,
 381 harvest tables, Secchi disks, laboratory glassware, etc. should be soak-chlorinated in 200 ppm solutions for 24–48 hours. This
 382 is most easily accomplished by placing these objects in the tanks that are filled with 200 ppm solutions of chlorine. Care should
 383 be taken to have all items completely submerged (use heavy items to weigh-down more buoyant objects). A good guide is to
 384 place everything (except those that are to be thrown away) that is loose or can be unsecured from its point of attachment, into
 385 the 200 ppm chlorine solution in their respective tanks.
- 386 In the case of those similar type items which are associated with ponds, they should be placed in a special series of tanks set
 387 up near their respective ponds. These tanks should be filled with 200 ppm chlorine solutions. Following soak-chlorination, these
 388 items should be allowed to dry and be exposed to natural UV (sunlight) sterilisation. They should be turned at least once to
 389 expose all areas of the items to direct sunlight.
- 390 Tools and machinery, such as tractors, trucks, portable and stationary power tools, etc., should be thoroughly cleaned with
 391 standard cleaning solutions. All traces of mud, shrimp feed, etc. must be removed from these items. Following this, disinfection
 392 of surfaces likely to have been contaminated in normal use should be rinsed off with an iodophor solution (at a concentration
 393 of 200 ppm) or cleaned with steam.
- 394 Small tools and instruments such as, scales and balances, test instruments, small power tools, etc., should be gently sponged
 395 off with 200 ppm of chlorine solutions if they are inert plastic or 200 ppm of iodophor if they are otherwise. These should then
 396 be placed back in their respective buildings during the formaldehyde fumigation. High precision electronic test equipment
 397 should not be subjected to the fumigation, especially if there has been little chance that it was ever contaminated.
- 398 iv) 'New-Water' Plumbing: all new-water plumbing which is contained within buildings, especially those which have blind ends or
 399 terminate in manifolds, should be filled with a minimum 200 ppm chlorine solution. The chlorine solution should be held in the
 400 lines for 24–48 hours minimum, followed by clean water rinsing. Pipes may also be disinfected by recirculating hot water
 401 (>60°C) through them for several hours.
 - 402 v) Uniforms, boots, etc.: all items worn or used by employees should be either disposed of or thoroughly washed and disinfected.
 403 In the case of clothing, such as coveralls, normal washing which incorporates a chlorine bleach is sufficient, especially if
 404 accompanied by sun drying. Other items, such as boots, gloves and other non-cloth items can be safely soak-chlorinated in a
 405 200 ppm chlorine solution. This should be followed by a freshwater rinse. These items should also be contained within their
 406 respective buildings during formaldehyde fumigation.
 - 407 vi) Feed items: all feed items, such as prepared feeds, fresh feeds (i.e. squid, bloodworms, frozen *Artemia*, bivalve molluscs, etc.)
 408 should be removed from the facility and replaced with new feeds from sources known to be free of contamination by shrimp
 409 disease-causing agents.

410 6. Neutralisation of halogens

411 Chlorine and iodine are highly toxic for aquatic animals and, in order to prevent serious accidents that could result from a manipulation error, it is
 412 recommended to neutralise these products with sodium thiosulfate α five moles of thiosulfate neutralise four moles of chlorine. The molecular
 413 proportions are the same for iodine.

414 Accordingly, in order to inactivate chlorine, the amount of thiosulfate should be 2.85 times the amount of chlorine (in grams):

415 Number of grams of thiosulfate = $2.85 \times$ number of grams of chlorine.

416 For iodine, the amount of thiosulfate should be 0.78 times the amount of iodine in grams:

- 417 Number of grams of thiosulfate = $0.78 \times$ number of grams of iodine.
- 418 It is also possible to prepare a thiosulfate solution at 1% by weight, in which case the neutralising volumes will be as follows (in ml):

419 1. for chlorine:
 420 $28.5 \times [\text{number of litres of the disinfecting solution} \times \text{concentration mg/litre}] / 100$

421 2. for iodine:
 422 it is necessary to multiply by 7.8 instead of by 28.5.

423 Both chlorine and ozone produce long-lived residual oxidant compounds in seawater. Seawater at 35 parts per thousand (ppt) salinity
 424 contains 60 ppm bromide ion, which produces hypobromite in the presence of ozone. Disinfected artificial seawater, at the same salinity,
 425 produces bromine and hypobromous acid. As these, along with other residual compounds, are toxic to larval oysters (and possibly other
 426 molluscs), treated seawater must be passed through an activated charcoal filter before being used for live mollusc larvae.

427 Alternative protocols for halogen neutralisation involve treatment with sodium or potassium thiosulfate.

428 Monitoring of residual oxidants must be carried out regularly, especially where temperature fluctuations occur. As residual ozone cannot be
 429 measured accurately in seawater, alternative monitoring protocols must be installed, such as a feedback loop.

430 Note: Exhaust systems should also be in place to remove toxic fumes (produced during disinfection) from enclosed work areas. Ensure
 431 compliance with local atmospheric regulations when discharging toxic fumes.

432 7. Re-stocking of disinfected farms

433 Following a TCU, restocking of the disinfected facilities or farms should be accomplished only with stocks known to be free of the diseases listed in
 434 the *Aquatic Code* or other emerging or significant diseases of concern.

435 *
 436 * *

437

438

439

440
441
442

APPENDIX 1.1.4.1

DISINFECTANTS AND DISINFECTION METHODS

443 The table below shows different indications and methods for disinfection for fish farm.

Processes	Indications	Method of use*	Comments
Physical			
Desiccation, sunlight	Fish pathogens on earthen bottoms	Dry for 3 months at an average temperature of 18°C	Drying period can be reduced by the use of a chemical disinfectant
Dry heat	Fish pathogens on concrete, stone, iron, ceramic surfaces	Flame-blower, blow-lamp	
Damp heat	Fish pathogens in transportation vehicle tanks	Steam at 100°C or more for 5 minutes	
Ultra-violet rays UV-C (254 nm)	Viruses and bacteria	10 mJ/cm ²	Minimum lethal dose
Ultra-violet rays UV-C (254 nm)	Infectious pancreatic necrosis (IPN) and nodavirus (VNN/VER ³) in water	125–200 mJ/cm ²	
Chemical			
Acetic acid	Infectious salmon anaemia (ISA)	0.04–0.13%	
Quaternary ammonia	Virus, bacteria, hands, plastic surfaces	0.1–1 g/litre for 1–15 minutes	IPN virus resistant
Calcium oxide ^a	Fish pathogens on dried earth-base	0.5 kg/m ² for 4 weeks	Replace in water and empty disinfected pools keeping the effluents at pH <8.5
Calcium hypochlorite ^a	Bacteria and viruses on all clean surfaces and in water	30 mg available chlorine/litre. Leave to inactivate for several days or neutralise with Na thiosulfate after 3 hours	Can be neutralised with sodium thiosulfate. See special recommendations
Calcium cyanamide ^a	Spores on earthen bottoms	3000 kg/ha on dry surfaces; leave in contact for 1 month	
Chloramine T	Destroys ISA	1% for 5 minutes	
Chloramine T	Destroys IPN	1% for 30 minutes	
Processes	Indications	Method of use*	Comments
Chlorine dioxide	ISA	100 ppm for 5 minutes	In water of low organic loading

444

Processes	Indications	Method of use*	Comments
Formic acid	Ensilage fish waste	pH <4 after at least 24 hours	Destroys bacterial fish pathogens and ISA but not IPN

3 Viral nervous necrosis /Viral encephalopathy and retinopathy

Formalin	Fish pathogens in sealed premises	Released from formogenic substances, generally trioxymethylene. Comply with instructions	Nodavirus resistant
Hydrogen peroxide	ISA virus	0.02–0.06%	
Iodine (iodophors)	Bacteria, viruses on nets, boots and clothing	200 mg iodine/litre for a few seconds	See special recommendations
Iodine (iodophors)	Hands, smooth surfaces	>200 mg iodine/litre a few seconds	
Ozone	Sterilisation of water, fish pathogens	0.2–1 mg/litre for 3 minutes	Costly and very toxic for fish and humans
Ozone in seawater	Surfaces, equipment	0.5–1 mg/litre TRO ⁴ for 30–60 minutes	
Poroxy compounds, e.g. Virkon	IPN virus	1% for 1 minute	
Peracetic acid	ISA virus	0.08–0.25%	
Sodium hydroxide ^a	Fish pathogens on resistant surfaces with cracks	Mixture: Sodium hydroxide, 100 g Teepol®, 10 g Calcium hydroxide, 500 g Water, 10 litres Spray, 1 litre/10 m ² Leave for 48 hours	The most active disinfectant Ca(OH) ₂ stains the surfaces treated; Teepol® is a tensio-active agent
Sodium hypochlorite ^a	Bacteria and viruses on all clean surfaces and in water	30 mg available chlorine/litre. Leave to inactivate for a few days or neutralise with Na thiosulfate after 3 hours	
Sodium hypochlorite ^a	Nets, boots and clothing	200 mg to 1 g available chlorine/litre for several minutes. Leave to inactivate for a few days or neutralise with Na thiosulfate after 3 hours	
Sodium hypochlorite ^a	Hands	Rinse with clean water or neutralise with thiosulfate	

445 a Dangerous – See precautions indicated in general recommendations

446 * The concentrations indicated are those for the active substance. NB: The chemicals must be approved for the prescribed use and used according to the
447 manufacturer's specifications.

4 TRO: Total residual oxidant

448 **Disinfectants for crustacean farms**

449 The following list comprises the disinfectants recommended for use in shrimp farms (the appropriate disinfectant regimes for each specific
450 application are discussed in the appropriate subsection):

- 451 – chlorine (as calcium hypochlorite, HTH™ or a bleach solution containing a sufficient concentration of hypochlorite);
- 452 – formaldehyde gas (from sublimated paraformaldehyde or concentrated formalin/potassium permanganate reaction);
- 453 – iodine (as contained in iodophors);
- 454 – lime (as calcium oxide or calcium hydroxide);
- 455 – UV light (from natural sunlight);
- 456 – ozone;
- 457 – steam;
- 458 – hot water (60°C);
- 459 – concentrated acids;
- 460 – desiccation;
- 461 – detergents (for general cleaning, with some degree of disinfection capability for many products).

462 *
463 * *

464